

Should you have questions regarding the identification of the firearm intended for your Galco product, you may also contact Galco’s customer service department at **800-874-2526** (during business hours) or by email at **customerservice@galcoholsters.com**.

⚠ WARNING Galco holsters are approved for use with multiple firearms. Care must always be taken to ensure your holster is an appropriate and approved fit for your firearm.

REPAIRS

Great care was taken to select the finest materials available to craft your Galco product. It was designed in accordance with the highest engineering standards and hand made using traditional leather craft practices that have become Galco hallmarks over five decades. In the unlikely event a repair is necessary to an unaltered Galco product, simply contact our Customer Service department at **800-874-2526** or **customerservice@galcoholsters.com**. We will issue you a Return Authorization (RA) number to print on the outside of your shipping container and provide you with detailed shipping instructions.

THANK YOU FOR YOUR PURCHASE !

Ankle Holsters Covered in this Product Information Guide

ANKLE GLOVE

The Ankle Glove™ holster is constructed from full grain Premium Steerhide and features a retention strap with a reinforced thumb break on most models. Additional comfort and breathability is provided by sheepskin padding.

ANKLE LITE

The Ankle Lite™ is constructed from Premium Center Cut Steerhide and features a retention strap with a reinforced thumb break. Additional comfort and breathability is provided by sheepskin padding.

COP ANKLE BAND

The Cop Ankle Band™ features an elasticized nylon holster pocket with comfortable acrylic fleece padding. The adjustable hook-and-loop closure retention strap with reinforced thumb break can be positioned to accommodate a variety of firearms (**See illustration B**).

ANKLE TRAUMA MEDICAL KIT


The ATM-KIT™ offers secure hook-and-loop closure and five neoprene pockets of various widths, each with a retention strap for security (**See illustration C**). It accommodates user supplied tools and equipment such as tourniquets, strap cutters, knives, multi-tools, bandages, clotting agents or other emergency rescue and first-aid gear.

All Galco ankle holster accomodate ankles up to 13” in circumference and feature a wide neoprene ankle-band and hook-and-loop closure.

ACCESSORIES


BOOT EXTENDER

The Boot Extender™ is compatible with all Galco ankle products. The Boot Extender adds 1-5” in the circumference and the suede shield protects the ankle cuff from boot-lace hooks. Perfect for use with boots and wider ankles.




ANKLE CALF STRAP

The Ankle Calf Strap™ counteracts the tendency of gravity to pull the ankle holster down and enables wear at a higher position on the leg. For use with the Ankle Guard, Ankle Glove, and Ankle Lite.



ANKLE SAFE

The Ankle Safe™ is designed to carry accessories, including spare ammo, for those who need convenience and concealment



INSPECTIONS + MAINTENANCE, ADDITIONAL USER RESPONSIBILITIES

⚠ WARNING It is the user’s responsibility to ensure that the Galco product remains serviceable and safe, and able to continue service within its design intent.

NOTICE It is the user’s responsibility to inspect the holster before and after each use for signs of excessive wear or loss of retention capability, and appropriate tightness of all hardware.

DO

NOTICE Ensure that all screws are tightened snugly. Applying a small amount of clear nail polish to the threads will minimize screw back out. Ensure that the holster provides secure gun retention in all circumstances.

Clean progressively as needed by wiping with a soft cloth, soft bristle brush, soft damp cloth, soft damp cloth with mild soap to remove stubborn grime. Do not saturate with water and do not run under the tap.

DON’T

⚠ WARNING Do not use a loaded firearm in a holster without first testing – with a firearm double-checked and verified to be unloaded – for proper firearm fit.

NOTICE Do not put Galco synthetic or leather products in the washing machine. Do not use any solvents of corrosive chemicals on this product.



Do not use artificial heat to speed up the drying process, i.e. from a hair-dryer, oven, radiator, direct sunlight, etc. Do not leave Galco products on the dashboard of your car in summertime. Do not leave Galco products exposed to direct sunlight or excessive heat for long periods of time.

Do not use LocTite® or threadlock. Outgassing from these adhesive compounds will adversely affect plastic, nylon and rubber parts.

The above care and maintenance instructions cannot substitute for your good common sense. Following our recommended care and maintenance tips will allow you to get the maximum service life from all of your Galco products.

⚠ WARNING Holsters designed and specified for a firearm with a rail-mounted light, trigger-guard mounted laser or light, or any other device mounted on its rail, trigger guard or other location on the firearm fully or partially enclosed by the holster (when holstered) should not be used with a firearm without the light, laser or other device attached to the firearm. Using the holster with the firearm only, without the attached accessory device may reduce the holster’s retention properties, resulting in firearm loss and/or subsequent discharge.

RELEASING A THUMB BREAK STRAP



Proper technique for releasing a thumb break retention strap is to drive the thumb briskly straight down through the snap (fig. 1). This fast, single motion will wedge the strap apart and place the thumb in the correct position to achieve a full firing grip prior to the draw.

Do not attempt to release the thumb break by pushing the strap apart with a sideways motion of the thumb (fig. 2). This is not only more difficult, it is slower and clumsier, and may also be impeded by body parts (belly, calf muscle/bone, etc.).

HOLSTER FIT / BREAK-IN ♣

Galco’s full grain leather holsters are made of the finest materials and are precision molded to specific firearms. It may appear the holster fit is too tight at first, but this is by design. We engineer our holsters to fit tightly knowing the leather fibers will relax to the proper fit with use.

⚠ WARNING UNLOAD YOUR FIREARM

(Chamber, magazine, cylinder) before testing holster fit.

If the holster has tension screws: Tension units are not pre-set at the factory. You may need to adjust them in order to holster your handgun for the first time. We recommend that you check your tension screw adjustments before each use. There is no reason to completely remove tension units. Do not use LocTite® on tension units. However, a single drop of clear nail polish applied to your tension screw threads may reduce its unwanted loosening.

If the fit is too tight when holstering your firearm the first time don’t force it. If you do force the firearm into the holster, it may be very difficult to remove. Instead, follow these simple steps to break in your new holster using a process called blocking:

1. Place the unloaded firearm in a heavy duty Ziploc® type bag , or cover it in 2-3 layers of plastic kitchen wrap. Do not cover the grip.
2. Once the firearm is completely seated in the holster, twist approximately 1/16” in both directions 6-12 times.
3. Allow the bagged/wrapped firearm to sit in the holster for approximately 15 minutes.
4. Remove the firearm from the holster and remove the bag/wrap from the firearm.
5. Insert the unloaded firearm into the holster, which should now be snug but not loose. If it still too tight, repeat the above steps until the holster is broken in to your satisfaction.
6. If necessary, repeat steps 1-6 with an additional heavy duty Ziploc type bag or additional 2-3 layers of plastic kitchen wrap.

NOTICE If your holster has a retention strap:

You may need to stretch the retention strap using your fingers only (no tools, no water, no chemicals, etc.) before you get it to snap.

1. Place the unloaded firearm in the holster.
2. Hold the firearm grip in your strong hand and the retention strap in your support hand.
3. Prepare the strap for stretching by grasping the snap and pulling the strap taut (removing the slack).
4. Twist the strap 90 degrees back and forth in a clockwise and counterclockwise rotation 10-12 times while keeping it taut.
5. Firmly push the firearm away from you while pulling on the strap and continue rotating the strap.
6. Release the tension for a moment and repeat two or three times.

7. Pull the strap over the back of the firearm without releasing tension.

8. While maintaining the strong tension, attempt to snap the retention strap closed.


9. Repeat step 5 as needed.

Following and repeating the above instructions is the only way to an ideal break-in and long service life with proper fit that will last many years.

It is common for the inside of a leather holster to scratch from a single holstering (called etching). A smooth leather lined holster will be even more subject to this normal occurrence. After this initial etching, the holster will custom fit your firearm.

ANKLE HOLSTER PLACEMENT


A



First-time users of ankle holsters often need to do some experimentation to find their most comfortable wearing position. Long-time users have found it most comfortable to wear ankle holsters with the gun slightly back of the anklebone toward the calf. (**See illustration A**). Your comfort zone is unique to your leg.


COP ANKLE BAND STRAP PLACEMENT

B



ANKLE TRAUMA MEDICAL KIT

C



The ATM-KIT does not include tools or supplies, only the pocketed ankle cuff, retention straps and optional boot extender panel. Emergency rescue tools and first aid kit supplies are sold separately by other sources.

TERMS OF SALE

Because we have no control over the use of our products, all Galco products are sold as is and “with all faults”. The entire risk as to the quality and performance of the product is with the buyer. Should the product prove defective following its purchase, the buyer and not the manufacturer, distributor, or retailer assumes the entire risk of all the necessary servicing or repairs. Under no circumstances shall Galco be liable for incidental or consequential damages, such as loss of use of property, commercial loss and loss of earnings or profits. The implied warranties of merchantability and fitness for a particular purpose and all other warranties, expressed or implied, are excluded from this transaction and shall not apply to the product sold. The determination of the fitness or the suitability of any product for a specific use is the responsibility of the buyer. The illustrations shown herein are typical as to the finish and application. Due to uncontrollable variances in color saturation, the actual product may differ slightly from that shown on our web site. Galco reserves the right to make changes in product built and/or sold by them at any time without incurring any obligation to make same or similar changes on products previously manufactured and/or sold by them. All Galco products are made in the U.S.A. and produced according to rigid specifications. Prices and models are subject to change without notice. Some states do not allow the exclusion or limitation of implied warranties or liability for incidental or consequential damages, so the above limitations and exclusions may not apply to you. Galco designs, features, and model names are the exclusive property of Galco International. Any and all persons including, but not limited to, individuals, firms and/or corporations are forbidden from imitating, copying or reproducing them in any way.